Philips LED DayLight 4

DRL STRIP 2.4 Click2



www.philips.com/support

EN LED Daytime Running Lights (DRL)

DE LED Tagfahrlicht-Set

FR Feux diurnes à LED

NL LED Daytime Running Lights (DRL)

ES Faros LED especiales de conducción diurna

IT Luci di marcia diurna a LED

PT Luzes dedicadas diurnas LED

RU Светодиодные дневные ходовые огни (DRL)

PL Specjalne dzienne światła pozycyjne LED

SV LED varselljus

NO LED-kjørelysmoduler

DA Specielt LED-kørelys til dagtimerne

SU LED päivä-ajovalot

PHILIPS

1 Important

Thank you for buying Philips
LED DayLight 4, the daytime
running light modules that will
make your driving experience
a safe and comfortable one.
Philips Original Equipment
Quality lighting products offer
the excellence, reliability, and
power you need.


The Philips guarantee applies provided that the product is handled properly for its intended use, in accordance with its operating instructions and upon presentation of the original invoice, indicating the date of purchase, dealer's name and model and production number of the product.

A Take time to read the Philips LED DayLight 4 installation guide before you install Philips LED DayLight 4 on your car. We recommend, that you carry the Philips LED DayLight 4 installation guide for reference with your vehicle documentation at all times.

Philips LED DayLight 4 modules have been tested and approved according to the daytime running lights regulation ECE R87.

E4-87R-00 0046 by KEMA BV Netherlands

⚠ The Philips LED DayLight 4 switches on / off automatically.




△ Important


- If your vehicle is equipped with a preinstalled daytime running light (DRL) system, you must disable it before installing Philips LED DayLight 4
- If your vehicle is equipped with low-beam daytime running light (DRL) system, use Philips LED DayLight compatibility set for low-beam DRL systems to make LED DayLight 4 compatible with your lighting system.


If necessary, consult a professional.

2 Content of the Philips LED DayLight 4 kit



3 Where to install Philips LED DayLight 4





△ Legal installation position ECE regulation 48

Make sure that the installation position of the Philips LED DayLight 4 modules conforms to the diagram above.


△ Horizontal tilting regulation

In order to follow the shape of the vehicle, Philips LED DayLight 4 optics have been especially designed to insure full conformity with the 10° (max) horizontal tilting angle regulation.

9


4 How to install Philips LED DayLight 4 on your car

How to install the LED modules using clip-on brackets




A Insert LED

DayLight 4 module into the bracket only after it is mounted on the car!




Installation on horizontal surface




2 Installation on vertical surface

Useful information for LED DayLight 4 customized installation



You may use the M5 tapped holes inside the module's body for any other type of mounting.



Space required for LED module installation

Make sure you have the above space available to install each module.

△ If necessary, cut out to exact size (see above). Depending on your car model, the customized installation may be performed:

- with or without using the clip-on brackets
- with or without cutting out the surface.

5 Wiring instructions

Perform the wiring installation of the LED DayLight 4 modules according to the numbered sequence below:

